

# 56\_BIM actual volumes

- **56\_BIM actual volumes** - Displays Navisworks .nwd model files by clicking on the slide image. You must paste the Autodesk Docs link to the .nwd file;

Prepare the file using the SIGNAX for Navis plugin to display the required volume.

image not found or type unknown





image not found or type unknown



---

Revision #2

Created 22 May 2022 21:17:52

Updated 8 May 2024 14:15:06 by Dmitry