3.3.2. Mobile app "Photomaker"

The mobile application has been developed to work efficiently with Theta and Insta 360 cameras. It allows you to quickly upload photos based on specific points on plans, bypassing the step of downloading photos from the camera to your computer and manually uploading photos through the web service INSPECTION

We recommend using the application on the Android operating system.

Preparation

1. Install the application:

- Android: Download from Google Play
- iOS: Download from the App Store

2. Open the application SIGNAX Photomaker.

3. Log into your SIGNAX account (if you need to create an account read 2.1 Authorization on the SIGNAX.)

4. In the main menu click "Choose company" - select the Company and the Project.

↑↓ **INTERNET**
Connected ✓

🏢 **CHOOSE COMPANY** ✗

🔄 **SYNCHRONIZATION**
Tap to sync ✗

📷 **CAMERA**
Press to connect ✗

Free memory: 26.77 GB

🌐 Connection   📷 Photo   ➡ Sending

5. Perform synchronization.

Workflow

1. Turn on the Theta V or Theta Z1 camera.
2. Connect to the camera's Wi-Fi (find the camera in the Wi-Fi networks on your smartphone) - the system will prompt you to enter the password, which is the numbers located on the bottom of the camera (as well as the numbers in the Wi-Fi network name).

THETAYN12100362OSC
Saved / No Internet access

3. Once you have connected the camera - click the "Photo" button in the main menu and choose the Block and the Plan.

EURASIA TOWER
Plans: 1

PROJECT 354
Plans: 1

RESIDENTIAL COMPLEX
Plans: 1

Connection   Photo   Sending

4. On the plan, choose the point and press "Take a photo."

SIGNAX/SIGNAX SAMPLE/PROJECT 354/FLOOR 14/1

Online   60%   26.75 GB

No data

VIEW   ⊕ TAKE A PHOTO

Connection   Photo   Sending

IMPORTANT! To avoid adjusting the direction of the photos, you should set up the camera as follows:

- The Theta Z1 camera's lens with the camera display on the side should face south on the plane (towards you).
- For the Insta360 X3 camera, the lens on the side with the camera display should be facing north on the plan (away from you).

IMPORTANT! Ensure the camera is set to photo mode (not video).


5. Click "VIEW" to review the photo taken.

6. If you need to delete the photo - click "Remove."

7. Disable the camera's Wi-Fi and connect to the office Wi-Fi or mobile network.

8. Go to the "Sending" section. To upload photos to the INSPECTION service, click "Send All Photos." Wait for the upload process to complete.

FLOOR 25/2
05/07/2024 12:23 PM

SEND ALL PHOTOS

Connection   Photo   Sending

FLOOR 25/2
05/07/2024 12:23 PM

SENDING DATA   ✕

Don't switch off the screen and
turn off the app

Photo upload: **0/2**

STOP

SEND ALL PHOTOS

Connection   Photo   Sending

15. After sending the data, you can delete the photos from your smartphone's memory by clicking "Delete Sent Photos."

Revision #13
Created 5 October 2023 12:01:27
Updated 7 May 2024 15:07:16 by SIGNAX SUPPORT